



NOTE  
 1. TO REWIND COMPRESSOR WITH CUMMINS BELT MUST BE ORIGINALLY CHARGED OVER.  
 2. THE ORDER OF AIR STARTING TANKS & THE AIR STARTING MOTOR'S APPROXIMATE  
 POSITIONS ARE SHOWN BELOW.

REVISIONS

NO.	DATE	DESCRIPTION
1		

CLASSIFICATION BOUNDARY DRAWING

SYMBOLS

(A) THE CHEMISTRY (GAS), OPERATOR AIR STARTING SYSTEM IS VERIFIED  
 OPERABLE UNDER NORMAL OPERATION WITH 3-PT-25.2A TO VERIFY THE  
 RELIABILITY OF TECHNICAL SPECIFICATION AS SHOWN POWER STATION AND  
 THE HSE ARE SATISFIED THAT THIS SYSTEM IS ADEQUATELY TESTED WITH  
 THE HSE'S APPROVED TEST CRITERIA AND OPERATIONS. HOWEVER, THE HSE  
 DO REQUEST THAT THE FOLLOWING OPERATIONS SHOULD BE TESTED AS PART  
 OF THE FINAL TEST PROGRAM AS THE CLASSIFIED MATERIAL.

FOR ISI CLASSIFICATION BOUNDARY DRAWING LEGEND AND SYMBOLS, SEE 11440-330-1.6.6.

CAUTION:  
 THE OPERATIONAL POSITION OF THIS SYMBOLIC DRAWING IS FOR REFERENCE ONLY.  
 THE OPERATIONAL POSITION OF THE ACTUAL SYSTEM SHOULD BE THE ACTUAL  
 PLANT OPERATIONS. REFER TO THE LATEST PLANT OPERATIONS  
 MANUAL FOR THE OPERATIONAL POSITION OF THE ACTUAL SYSTEM.

VIRGINIA POWER  
 NORTH CAROLINA POWER  
 DESIGNING AND CONSTRUCTION  
 RICHMOND, VIRGINIA

ISI CLASSIFICATION BOUNDARY DRAWING  
 EMERGENCY DIESEL GENERATOR #3  
 SURRY POWER STATION UNIT 1  
 VIRGINIA POWER

REV	DATE	BY	CHKD	APP'D	DESCRIPTION	REV	DATE	BY	CHKD	APP'D	DESCRIPTION
1	08/14/87				INITIAL ISSUE FOR REVISION 2 OF 11440-P3-040C	1					



PDR RIDS

881201Φ311

