



- NOTES:
- 1 - CALIBRATION CURRENT INPUT
  - 2 - TRIP LIMIT, OUT OF FILE OR POWER FAILURE
  - 3 - FOR JUMPERS ON TRIP UNITS SEE A.T.S. CAB. 'D' INTERCONNECTION DIAGRAM DWG. NO. C-22385-C 5A19 E21
  - 4 - CHECK TRIP UNIT IF IN DRYWELL INTERFERENCE OR LO LO REACTOR LEVEL

NIAGARA MOHAWK  
NIAGARA MOHAWK POWER CORPORATION

NIAGARA MOHAWK POWER CORPORATION  
NIAGARA MOHAWK POWER CORPORATION  
INTERCONN. WIRING DIAG.  
INSTRUMENTATION SYS.  
(REACTOR INSTRUMENTATION  
MAIN STEAM)

2	4	W. NEEDLE CABLE 1859 TO UNIT 36-000-M	1/8"	1/2"		
3	4	1/8" BORE PLASTIC TUBING 1/2" DIA.	1/8"	1/2"		
4	4	1/8" BORE PLASTIC TUBING 1/2" DIA.	1/8"	1/2"		
5	4	1/8" BORE PLASTIC TUBING 1/2" DIA.	1/8"	1/2"		
6	4	1/8" BORE PLASTIC TUBING 1/2" DIA.	1/8"	1/2"		
7	4	1/8" BORE PLASTIC TUBING 1/2" DIA.	1/8"	1/2"		
8	4	1/8" BORE PLASTIC TUBING 1/2" DIA.	1/8"	1/2"		
9	4	1/8" BORE PLASTIC TUBING 1/2" DIA.	1/8"	1/2"		

NOTE: SEE DWG. C-22385-C 5A19 E21 FOR WIRING TO ANNUNCIATOR CAB. 1584

30X  
Ref # 351

**POOR ORIGINAL**

RIDS

0270110

