



NOTES

1. LOADS AND COMPONENTS NOT HAVING SPECIFIC LOAD PATHS SHOWN CAN BE MOVED ANYWHERE ON OPERATING FLOOR EXCEPT OVER REACTOR VESSEL WHEN THE MISSILE SHIELD HAS BEEN REMOVED FOR MAINT. OR REFUELING
2. CRANE OPERATOR SHOULD AVOID HANDLING LOADS OVER THE MANIPULATOR CRANE. SEE DWG. B1022-M-002 POSITION OF THE MANIPULATOR CRANE WILL VARY

| | |
|-------------------------|-------------|
| LOAD: | LOAD PATHS: |
| ① REACTOR VESSEL HEAD | — |
| RV HEAD LIFTING RIG | — |
| TRI-POD | — |
| ② REACTOR INTERNALS | ▨ |
| ③ INTERNALS LIFTING RIG | ▨ |

| | |
|---|---|
| CAROLINA POWER & LIGHT COMPANY | |
| NUCLEAR PLANT ENGINEERING DEPARTMENT - RALEIGH, N. C. | |
| PLANT: | ROBINSON STEAM ELECTRIC PLANT |
| TITLE: | CONTROL OF HEAVY LOADS SAFE LOAD PATHS REACTOR CONTAINMENT BUILDING |
| DRAWN BY: | GER |
| CHECK BY: | 2/2/59 |
| BY: | lms |
| DATE: | 7-2-59 |
| SCALE: | NONE |
| DWG. NO.: | B1022-M-001 |
| SHEET 2 OF 2 | A |

8108170283

17"

11"

8.5"

8.5"

11"

17"

17"

11"

8.5"

8.5"

11"

17"

RIDS

8108170283

