



NOTES:

1. AIR RECIRC. FAN MOTOR OR COMPONENTS LOAD PATH LIFT MOTOR AND HOLD IN CRANE LEG, ROTATE THE CRANE AND PLACE THE MOTOR IN LAYDOWN AREAS FOR MAINT OR IN THE EQUIPMENT HATCH FOR REMOVAL
2. LOADS CANNOT BE HANDLED OVER THE REACTOR VESSEL WHEN THE MISSILE SHIELD HAS BEEN REMOVED FOR MAINT. OR REFUELING
3. CRANE OPERATOR SHOULD AVOID HANDLING LOADS OVER THE MANIPULATOR CRANE SEE DWG B1022-M-002 POSITION OF THE MANIPULATOR CRANE WILL VARY.

CAROLINA POWER & LIGHT COMPANY					
NUCLEAR PLANT ENGINEERING DEPARTMENT - RALEIGH, N. C.					
PLANT:	ROBINSON STEAM ELECTRIC PLANT				
TITLE:	CONTROL OF HEAVY LOADS SAFE LOAD PATHS REACTOR CONTAINMENT BUILDING				
DRAWN BY:	CHKD BY:	ASST. ENGR.:	APPROVED BY:	SCALE:	SHEET NO. OF TOTAL SHEETS
SEM	TRW	236	WING	7/28	B1022-M-001 A

8105170289

17"

11"

8.5"

8.5"

11"

17"

17"

11"

8.5"

8.5"

11"

17"

RIDS

8108170289

