



RELAY	DESCRIPTION	USER/TYPE	REMARKS
ST	START UP TRANS EA	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
LOK	START UP TRANS EA LOCKOUT RELAY	02/11/64	
ST	START UP TRANS SB	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
LOK	START UP TRANS SB LOCKOUT RELAY	02/11/64	
ST	STATION SERVICE TRANS EA	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	STATION SERVICE TRANS SB	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	CONDENSATE PUMP EA	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	CONDENSATE PUMP SB	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	CHARGING PUMP EA	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	CHARGING PUMP SB	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	DIESEL GENERATOR	02/25/70	LOC IN MAIN CONTROL ROOM
LCP	OVER CURRENT RELAY	02/25/70	
ST	DIESEL GENERATOR	02/25/70	
LCP	UNDER VOLTAGE RELAY	02/25/70	DIESEL GENERATOR 2A 3/0 LOGIC CIRCUIT
ST	DIESEL GENERATOR	02/25/70	
LCP	UNDER FREQUENCY RELAY	02/25/70	DIESEL GENERATOR 2A 3/0 LOGIC CIRCUIT
ST	START UP TRANS EA	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
LOK	START UP TRANS EA LOCKOUT RELAY	02/11/64	
ST	START UP TRANS SB	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
LOK	START UP TRANS SB LOCKOUT RELAY	02/11/64	
ST	STATION SERVICE TRANS EA	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	STATION SERVICE TRANS SB	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	CONDENSATE PUMP EA	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	CONDENSATE PUMP SB	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	CHARGING PUMP EA	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	CHARGING PUMP SB	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	DIESEL GENERATOR	02/25/70	
LCP	OVER CURRENT RELAY	02/25/70	
ST	DIESEL GENERATOR	02/25/70	
LCP	UNDER VOLTAGE RELAY	02/25/70	
ST	DIESEL GENERATOR	02/25/70	
LCP	UNDER FREQUENCY RELAY	02/25/70	

NOTES

1. S - DRIVES MAIN CONTROL BOARD IN MAIN CONTROL ROOM.
2. BUS 2F UNDER FREQUENCY TRIP - RELEASER 9x-DPDS PARALLEL WITH SYSTEM.
3. METER 6.8. 2 RELEASE TYPE DS-10-10-D.
4. PHYSICAL ARRANGEMENT OF THE SWITCHGEAR CELLS THROUGH IS TO RIGHT TO LEFT RESPECTIVE.
5. FOR KEY INTERLOCKING OF GEAR 55-2P1536 (D-207005) FOR KEY INTERLOCKING OF GEAR 55-2P1536 (D-207005).
6. FOR KEY INTERLOCKING OF GEAR 55-2P1536 (D-207005).
7. LCP - DRIVES LOCAL CONTROL PANEL.
8. S - DRIVES MAIN CONTROL BOARD IN MAIN CONTROL ROOM.

REFERENCE DWS

D-207001 - SINGLE LINE DIAGRAM SYSTEM IS MAIN CONTROL ROOM
A-207002 - ELECTRICAL GENERAL NOTES & NOTES
B-207003 - LOGIC CIRCUIT IN MAIN CONTROL ROOM

APERTURE CARD

ALABAMA POWER COMPANY
 1000 POWER HOUSE AVENUE
 MOBILE, ALABAMA 36688
 D-207005

9712300426

PDR RIDS

9712300426

