

TABLE I
 TURBINE CONDITIONAL SUPERVISORY ALARMS


ALARM FUNCTION	INITIATING DEVICE	DEVICE LOCATION	TYPE OF ALARM
HPCI OIL LO PRESS	PS - *	LOCAL	LOW
HPCI FLOW LOW	FIS-N651	CR	LOW
VACUUM TANK PRESSURE LOW	PSL - *	LOCAL	LOW

TABLE II
 TURBINE SUPERVISORY INDICATING LIGHTS

ACTUATING DEVICE	TRIP FUNCTION	COLOR
SEE VPF REF 8 IDENTIFICATION OF ACTUATING DEVICES	TURBINE GOVERNOR VALVE OPEN	RED
	TURBINE GOVERNOR VALVE CLOSED	GREEN
	STOP VALVE OPEN	RED
	STOP VALVE CLOSED	GREEN

TABLE III
 DEVICES

DEVICES	COLOR
VACUUM PUMP	ON (RED)
VACUUM TANK COND PUMP	OFF (GREEN)
AUX OIL PUMP	OFF (GREEN)



REVISIONS

NO.	DATE	DESCRIPTION	BY	CHK'D BY
24	11/15/85	CHANGED PER GEN INSTRUCTIONS
25	12/1/85
22	11/17/85
23	11/17/85
20	11/17/85
12	11/17/85
17	11/17/85

30X 012

I certify that the microfilm image contained on this microfilm was made in the normal and regular course of business. This is a true, full, correct and complete reproduction and replacement for and/or in lieu of original documents owned by the federal government of commerce.