







Horizontal Stress

Vertical Stress

Mises Stress

Figure 8-24. PCCV Liner Model, Posttest Analysis, Case 6, Stress Contour, at P = 3.3 Pd
(Stresses in psi; multiply by 0.00690 for MPa)




Horizontal Strain

Vertical Strain

Effective Plastic Strain

Figure 8-25. PCCV Liner Model, Posttest Analysis, Case 6, Strain Contour, at P = 3.3 Pd





Horizontal Stress



Vertical Stress

Mises Stress



Figure 8-26. PCCV Liner Model, Posttest Analysis, Case 7, Stress Contour, at P = 3.3 Pd
 (Stresses in psi; multiply by 0.00690 for MPa)



Horizontal Strain




Vertical Strain



Effective Plastic Strain

Figure 8-27. PCCV Liner Model, Posttest Analysis, Case 7, Stress Contour, at P = 3.3 Pd









Horizontal Stress

Vertical Stress

Mises Stress

Figure 8-28. PCCV Liner Model, Posttest Analysis, Case 8, Stress Contour, at P = 3.3 Pd
 (Stresses in psi; multiply by 0.00690 for MPa)




Effective Plastic Strain

Vertical Strain

Horizontal Strain

Figure 8-29. PCCV Liner Model, Posttest Analysis, Case 8, Strain Contour, at P = 3.3 Pd









Horizontal Stress

Vertical Stress

Mises Stress

Figure 8-30. PCCV Liner Model, Posttest Analysis, Case 9, Stress Contour, at P = 3.3 Pd
(Stresses in psi; multiply by 0.00690 for MPa)



Effective Plastic Strain

Vertical Strain

Horizontal Strain

Figure 8-31. PCCV Liner Model, Posttest Analysis, Case 9, Strain Contour, at P = 3.3 Pd